

Inxpect MSK-101-POE Rest API

Version: 1.0.3

Inxpect SPA

Abstract

This document describes the Rest API provided by MSK-101-POE sensor

Contents

1	Overview	3
2	Update process	3
3	APIs	5
3.1	/detectionStatus (GET)	6
3.1.1	Returned value	6
3.2	/alarmStatus (GET)	7
3.2.1	Returned value	7
3.3	/sensorConfiguration (GET and PUT)	8
3.3.1	Configuration object encoding	8
3.4	/sensorPositionStatus (GET)	12
3.4.1	Returned value	12
3.5	/sensorInfo (GET)	12
3.5.1	Returned value	12
3.6	/calibrationStatus (PUT)	14
3.6.1	Input argument	14
3.6.2	Return value	14
3.7	/calibrationData (GET)	14

3.8	/calibrationFineTuning (GET/PUT)	14
3.8.1	Fine calibartion object encoding	15
3.9	/installationConfigurations (GET)	15
3.9.1	Returned value	15
3.10	/netSettings (GET and PUT)	16
3.10.1	Configuration encoding	17
3.11	/changePassword (PUT)	18
3.11.1	Password encoding	18
3.11.2	Return value	18
3.12	/comBoardName (GET and PUT)	18
3.12.1	Name encoding	18
3.12.2	Return value	18
3.13	/login (PUT)	19
3.13.1	Password encoding	19
3.13.2	Return value	19
3.14	/logout (PUT)	19
3.14.1	Return value	19
3.15	/sensorReset (PUT)	19
3.15.1	Return value	20
3.16	/comboardReset (PUT)	20
3.16.1	Return value	20
3.17	/updateToken (GET)	20
3.17.1	Return value	20
3.18	/eventLog (GET)	21
3.18.1	Return value	21
3.19	/startProcessUpdate (PUT)	22
3.19.1	Argument encoding	22
3.20	/startManifestUpdate (PUT)	22
3.20.1	Return value	22
3.21	/chunkManifestUpdate (PUT)	22
3.22	/stopManifestUpdate (PUT)	23
3.22.1	Return value	23
3.23	/startFileUpdate (PUT)	23
3.23.1	Return value	23
3.24	/chunkFileUpdate	24
3.25	/stopFileUpdate	24
3.25.1	Return value	24
3.26	/stopProcessUpdate	24

3.26.1 Argument	24
3.26.2 Return value	25

1 Overview

This document describes the MSK-101-POE Rest API interface. This device has an ethernet outlet that can be used to power the device (POE) and to communicate with it. Communication is implemented by an HTTPS Rest API that allows reading/writing the device configuration and retrieve the device status.

The device communicates over a secure HTTP connection (HTTPS) and the client must install the proper certificate which is available at (<https://www.inxpect.com/security/tools>)

Most of the operation on the device are restricted to authenticated clients. A client needs to login to get authenticated. In order to login a client shall provide the device password and will get a session token that shall be added to any http call as an header in the form: **Authorization: Bearer token** where token is the verbatim token as received on login success.

Since tokens have an expiration date which is unknown the client must be ready to handle the unauthorized error (HTTP 401). If any call fails with such an error the client shall login and repeat the original call.

2 Update process

The MSK-101-POE sensor allows upgrading all its software components OTC (over the cable). The upgrade process is not trivial as there are several components in the system with their own software on board. On top of this the firmware is signed to guarantee system security and this introduces some further complexity. Update packages are available as IFW files which are distributed by Inxpect and cannot be created or manipulated by anyone else. An IFW file is just a zipped file containing the files and metainformation to upgrade one system component. An IFW file *MUST* contain a special file

named package.json which describes the whole package. This JSON object has the following structure:

```
{"f": "CBPOE_v1209.bin", "v": "1.209", "df": 2,  
"dst": 1, "vc": 1209, "dm": 1}
```

the “dst” field specifies the target subcomponent for which this was is meant. The system has three different components which can be upgraded:

- MSK-101 core system
- Communication board
- Configuration web interface (web server)

If the destination is either MSK-101 core system or the communication board then the “f” field specifies the file with the device firmware. If the destination is the web server then “f” contains the name of another json file describing the multi file web server update (this file is named contents.json). Since updating the whole server may take some time there is a mechanism to verify what really needs to be updated. The client performing the update shall GET the following resource on the device:

msk101poe-xxxxx.local/contents.json

contents.json looks like this:

```
{"dm": 0, "fA": [{"f": "static/favicon.ico.gz",  
"d": "B75U5szUcv12LI0xB2qY81m84aH+M4/FD3odmQQ4eLo=",  
...},  
"df": 0, "v": "1207", "vc": 1207}]
```

The file contains an array (“fA”) with the list of files for the web server. Each file is described by its name and by its fingerprint. The contents.json retrieved from the device can be compared to the one stored in the IFW package and only the files whose fingerprint is different shall be sent to the device. The ones whose fingerprint is unchanged can be skipped.

The other fields of the package.json are the following ones:

- v is the version of the component (string value)
- vc is the version of the component (numeric value suitable for comparison)
- dm is the device mode this file is meant for
- df is the device family this file is meant for

For any file that is meant for the device there must be a corresponding file with the same file name and the extra extension “.mf” which is its meta information. For example:

```
CBPOE_v1209.bin  
CBPOE_v1209.bin.mf  
package.json
```

In this example we have the package.json descriptor and one file (CBPOE_v1209.bin) with its corresponding meta information. The package can contain any number of files for the device but they must belong to the same component.

Once a client has unpacked and read the IFW file it can start the actual update process which is composed by the following steps:

1. Start an update session for a given component (e.g. core sensor firmware)
2. Start update file meta information
3. Send meta information chunks (one by one)
4. Stop update meta information
5. Start sending file data
6. Send data chunks (one by one)
7. Stop sending data
8. Stop update session

Steps 2-7 must be repeated for each file to send.

3 APIs

The APIs provided by MSK-101-POE are listed in this section. Each API is described with its parameters and generated output. APIs arguments and results are encoded as JSON objects.

3.1 /detectionStatus (GET)

This endpoint allows retrieving the information about the latest targets detected by the sensor. When the sensor is not detecting any target it returns the latest detected targets so the information is never lost. The information is retained until a valid /detectionStatus request is done. The elapsedTime and acqIdx fields can be used to discard information that has already been processed.

3.1.1 Returned value

```
{
  "fps":<I:value>, "acqIdx":<I:value>,
  "elapsedTime":<I:value>,
  "targets": [ {"distance":<I:value>,
    "rcs":<I:value>,
    "id":<I:value>
  }
]
}
```

Where:

- fps is the frame per seconds that the sensor is able to process. Under normal conditions this value is greater or equal to 100
- acqIdx is the frame counter (a frame corresponds to the acquisition of the radar signal)
- elapsedTime how long has passed since these targets have been detected
- targets is an array of detected moving targets. Each target is described by the following info:
 - distance is the distance in [mm] from the sensor
 - rcs is a measure of the “size” of the detected target. For calibrated sensor this value is on average greater than 1000 when the target is the object used for calibration or anything bigger than that
 - id is the target identifier. The sensor tracks targets and assign them an ID. This identifier may change if a target is lost

3.2 /alarmStatus (GET)

This endpoint allows retrieving the latest alarm status and the last status when an alarm occurred. When the sensor is not detecting any alarm it returns the latest detected targets so the information is never lost. The information is retained until a valid /alarmStatus request is done. The elapsedTime and acqIdx fields can be used to discard information that has already been processed.

3.2.1 Returned value

```
{
  "fps": <I:value>, "acqIdx": <I:value>, "elapsedTime": <I:value>,
  "alarms": [ {"type": <I:value>,
    "cause": <I:value>,
    "target": {"distance": <I:value>,
      "rcs": <I:value>
    }
  }
]
}
```

Where:

- fps is the frame per seconds that the sensor is able to process. Under normal conditions this value is greater or equal to 100
- acqIdx is the frame counter (a frame corresponds to the acquisition of the radar signal)
- elapsedTime how long has passed since these targets have been detected
- alarms is an array with the latest alarms. Each alarm is described by the following fields:
 - type specifies the type of the alarm. It can be:
 - * 1 for an alarm generated by a detected target
 - * 2 for an alarm generated by a fault situation
 - * 3 for an alarm generated by a tampering situation
 - cause specifies the root cause of the alarm.
 If the alarm is triggered by a moving target then this value can be:
 - * 4 if the alarm has been generated in the alarm area
 - * 2 if the alarm has been generated in the pre-alarm area

If the alarm is generated by a tampering situation its value can be:

- * 2 if the sensor has been moved
- * 3 if the sensor has been masked

If the alarm is generated by a fault situation its value can be:

- * 100 for input voltage out of range
- * 101 for detection error
- * 102 for security error
- * 103 for HW head fault
- * 104 for masking
- * 105 for motion detector not responding
- * 106 for masking not ready
- * 107 for corrupted storage
- * 1001 for communication fault

- target is an array of detected moving targets. Each target is described by the following info:
- distance is the distance in [mm] from the sensor
- rcs is a measure of the “size” of the detected target. For calibrated sensor this value is on average greater than 1000 when the target is the object used for calibration or anything bigger than that
- id is the target identifier. The sensor tracks targets and assign them an ID. This identifier may change if a target is lost

3.3 /sensorConfiguration (GET and PUT)

Handles the sensor configuration. Most of the values are expressed as integer numbers and shall not be restricted to a subrange. The JSON definition here below shows the typical range just for convenience but there is no guarantee these ranges won’t change in the future.

3.3.1 Configuration object encoding

The configuration object is returned when the endpoint is read via a GET operation and it is stored on the device when it is PUT.

```
{"configuration": {"alarmDistance": <I: [minDist, maxDist]>,
                    "preAlarmDistance": <I: [minDist, maxDist]>,
```

```

    "alarmSensitivity":<I:[128:228] or [0:2]>,
    "mountHeight":<I:[1000-4000]>,
    "mountElevation":<I:[+90,-90]>,
    "mountRotation":<I:[-180,+180]>,
    "mountAzimuth":<I:[-180,+180]>,
    "calibrationCoefficient":<I:[300,50000]>,
    "ledMode":<I:enumeration>,
    "channel":<I:[0-14]>,
    "configurationsCount":<I>,
    "country":<String:[3 character ISO code]>,
    "antiMaskingMode":<I:enumeration>,
    "antiMaskingDelay":<I:enumeration>,
    "antiMaskingExitMode":<I:enumeration>,
    "antiTamperMode":<I:enumeration>,
    "antiTamperExitMode":<I:enumeration>,
    "numConflictingSensors":<I:[0,50]>,
    "ssMode":<I:enumeration>,
    "ssMinDist":<I:[minDist,maxDist]>,
    "ssMaxSize":<I>,
    "ssNumMaxZones":<I>,
    "ssManualZones": [{"min":<I>, "max":<I>}]
  },
  "version":<I>
}

```

Where:

- alarmDistance: the length of the alarm area expressed in millimeters
- preAlarmDistance: the length of the pre-alarm area expressed in millimeters. This value must be greater or equal to the alarmDistance. In case there is no pre alarm then this value shall be equal to the alarmDistance
- alarmSensitivity: defines the level of pet tolerance. Higher values correspond to decreasing sensibility and increasing pet tolerance. The value of this parameter is a byte expressing a percentage [0-100] with the first bit set to 1. In other words the value is: percentage | 0x80 where percentage is a value in the [0-100] range. When the percentage is set to 75 (parameter is 75 | 0x80) the sensor triggers an alarm for a target whose size is comparable to the one used during calibration.

Percentage values greater than 75 mean the sensor is less sensible and triggers alarms for targets bigger than the one that calibrated the sensor. This value can be also expressed in another equivalent way as 0, 1 or 2.

In particular:

- 0 is the same of a percentage of 83
- 1 is the same of a percentage of 50
- 2 is the same of a percentage of 17 When you set a percentage of 83, 50 or 17, it's possible to see in the next get response the same value expressed as 0, 1 or 2.
- mountHeight: defines the installation height in millimeters
- mountElevation: defines the sensor pitch. Usually this value is negative as negative values mean the sensor points downward. Values close to 0 mean the sensor is pointing parallel to the underlying ground.
- mountRotation: defines the sensor rotation. Values close to 0 degrees implies the sensor antenna is horizontal (volumetric mode) while values close to 90 degrees imply the sensor antenna is vertical (barrier mode)
- mountAzimuth: this value specifies the installation azimuth
- calibrationCoefficient: this value is used to calibrate the sensor in the environment where it operates. The correct value can be set using the automatic procedure (see the calibrationStatus api) or it can be manually set.
- ledMode: defines the led mode behavior.
 - 0 for normal led mode (red for alarm condition, blue for detected targets but no alarm yet, blinking red for pre alarm)
 - 1 for disabled mode
- channel: this parameter can be used to avoid interferences among sensors working in the same environment. 0 means this sensor is alone, 1 corresponds to channel A, 2 to channel B and so on
- numConflictingSensors: number of conflicting sensors in this environment. Each of them shall have a different channel to avoid interferences
- antiMaskingMode: specifies the anti masking mode. If this field is set you have to set also antiMaskingDelay. The parameter can take these values:
 - 0 for normal mode
 - 1 for disabled mode
 - 2 for aggressive mode (in this case anti masking is more sensible but it can generate false masking conditions if the sensor is exposed to direct rain)

- antiMaskingDelay: specifies the time that the sensor must see a masking alarm before signaling it. If this field is set you have to set also antiMaskingMode. The parameter can take these values:
 - 0 if sensor must signal a masking immediately
 - 1 if sensor must wait 30s in masking before signaling it
 - 2 if sensor must wait 120s in masking before signaling it
 - 3 if sensor must wait 300s in masking before signaling it
- antiMaskingExitMode: specifies the anti masking exit mode. The parameter can take this value:
 - 0 if sensor must exit from masking automatically
- antiTamperMode: specifies the anti tamper mode. The parameter can take these values:
 - 0 for disabled mode
 - 2 for tamper on sensor moved mode
- antiTamperExitMode: specifies the anti tamper exit mode. The parameter can take these values:
 - 0 if sensor must exit from a tamper situation automatically
 - 1 if sensor can exit from a tamper only with after a new set of configuration parameters
- country: the ISO3 code of the country where the sensor operates
- configurationsCount: this value is read only and counts the number of times the sensor has been configured. The value is returned when the configuration is fetched (GET) and it shall not be present when the configuration is stored (PUT). This value is reset on factory restore.
- version: the configuration format version. The value is returned when the configuration is fetched (GET) and it shall not be present when the configuration is stored (PUT).
- ssMode: semi statics mode. It can take one of the following values:
 - 0 for disabling semi statics
 - 1 for automatic mode 1 (i.e. max 2 semi static objects whose position is automatically found by the sensor and with a max size of 1.5 meters)
 - 2 for automatic mode 2 (i.e. max 3 semi static objects whose position is automatically found by the sensor and with a max size of 2.5 meters)
 - 3 for semi automatic mode (i.e. the position of semi statics is automatically found by the sensor but the max number and size is set by the user)

- 4 for manual mode (everything is controlled by the user)

When the configuration is saved the caller can specify only the fields that must change. All the unspecified fields will hold their current value. On configuration save the operation returns a JSON object like the following:

```
{"errorCode":code}
```

An error code 0 means no error (in that case the errorDesc is not present)

3.4 /sensorPositionStatus (GET)

This endpoint returns current values of elevation and rotation

3.4.1 Returned value

```
{"elevation":<I>, "rotation": <I>}
```

Where:

- elevation is the sensor current pitch. Negative angles mean the sensor is pointing downward
- rotation is the sensor current rotation. Values around 0 mean the sensor is horizontal (volumetric) while values around 90 mean the sensor is vertical (barrier)

3.5 /sensorInfo (GET)

Returns the sensors info (e.g. model, family, fw version)

3.5.1 Returned value

```
{"sensorInfo": {"model":<I>, "family":<I>,
                "fwVersion":<I>,
                "deviceId":<I>,
                "minDistance":<I>,
                "maxDistance":<I>,
```

```

    "minAngle":<I>, "maxAngle":<I>} ,
"comBoardInfo": {"model":<I>,
    "family":<I>,
    "fwVersion":<I>,
    "deviceId":<I>,
    "pinResetRequired":<I>}
}
```

The sensor info is split between the actual radar sensor and the communication board which is used to communicate over ethernet. For the sensor the following info is available:

- model: the device model (must be 1 for current version of MSK-101-POE)
- family: the device family (must be 5 for MSK-101-POE devices)
- fwVersion: the firmware version
- deviceId: the device unique id
- minDistance: the minimum distance from the sensor at which a target can be detected
- maxDistance: the maximum distance from the sensor at which a target can be detected
- minAngle: the minimum angle from the sensor point of view at which a target can be detected
- maxAngle: the maximum angle from the sensor point of view at which a target can be detected

The span between minAngle and maxAngle defines the sensor FOV

For the communication board the following info is available:

- model: the com board model (must be 1 for the ethernet board embedded in the MSK-101-POE)
- family: the com board family (must be 5 for the ethernet board embedded in the MSK-101-POE)
- fwVersion: fw version of the communication board
- deviceId: unique com board device id
- pinResetRequired: specifies if the com board has a pin/password which the user needs to change

3.6 /calibrationStatus (PUT)

This endpoint allows starting/stopping/saving a sensor calibration.

3.6.1 Input argument

```
{"operation":<I:[0=stop,1=start standard,2=start zone based,3=save]>}
```

3.6.2 Return value

The API returns the status of the operation performed with an object with the following format:

```
{"errorCode":<I:[error code, where 0 means no error]>}
```

When the operation is “stop” the error code signals both blocking errors and warnings. In particular:

- 0 means everything is OK
- 1001 means calibration data is poor, it is usable but the info is not very good
- any other value means the calibration procedure failed and the calibration data cannot be saved on sensor

3.7 /calibrationData (GET)

This endpoint allows retrieving information on the latest calibration performed (the information is not persisted on sensor so it does not survive reboot cycles). The returned data are encoded as a CSV file.

3.8 /calibrationFineTuning (GET/PUT)

This endpoint allows to retrieve and specify settings to customize calibration values in some specified zone.

3.8.1 Fine calibration object encoding

```
{
  "fineTuningZones": [
    {
      "min": <I>,
      "max": <I>,
      "scaleFactor": <I>
    }
  ]
}
```

Where:

- min is the lower bound of the zone (indicated as distance in millimeters from the sensor)
- max is the upper bound of the zone (indicated as distance in millimeters from the sensor)
- scaleFactor is the value to scale the calibration value (expressed in percentage). A factor greater than 100 makes the detection less sensible

The maximum number of zones are 5. If a zone is not set, the old value persists. In PUT requests, the sensor returns a JSON object like the following:

```
{"errorCode":code}
```

An error code 0 means no error (in that case the errorDesc is not present)

3.9 /installationConfigurations (GET)

This endpoint allows retrieving the supported and optimal sensor configurations.

3.9.1 Returned value

```
{"installations": [{"minDistance": <I>,"maxDistance": <I>,
                    "minElevation": <I>,"maxElevation": <I>,
                    "minHeight": <I>,"maxHeight": <I>},
```

```

    "orientation": <I>
  },{...}]
}
```

Where installations is an array with the supported and optimal configurations

- minDistance is the minimum distance at which this configuration can detect targets (**value in centimeters**)
- maxDistance is the maximum distance up to which this configuration can detect targets (**value in centimeters**)
- minElevation is the minimum elevation for this configuration to apply (**value is positive when sensor is pointing downward**)
- maxElevation is the maximum elevation for this configuration to apply (**value is positive when sensor is pointing downward**)
- minHeight is the minimum height for this configuration to apply (**value in centimeters**)
- maxHeight is the minimum height for this configuration to apply (**value in centimeters**)
- orientation is the orientation for this configuration to apply (0 for horizontal and 1 for vertical)

For example we could have the following configuration:

```
{"minDistance": 250,"maxDistance": 1600,
 "minElevation": 12,"maxElevation": 18,
 "minHeight": 175,"maxHeight": 224,
 "orientation": 0
}
```

This configuration specifies that the sensor can be installed with an height in the [175,224] cm range, with an inclination in the [-12,-18] degrees range, and horizontal orientation (volumetric). In this configuration the detection range is in the [250,1600] cm range.

3.10 /netSettings (GET and PUT)

This endpoint allows reading/writing the network configuration for the device.

3.10.1 Configuration encoding

The configuration is encoded into a JSON object like this:

```
{"netConfiguration":<I>,
  "staticAddress":<String:address>, "subnet":<String:address>,
  "gateway":<String:address>, "curNetConfiguration":<I:[bitMask]>,
  "curHostAddress":<String:address>, "curSubnet":<String:address>,
  "curGateway":<String:address>
}
```

Where netConfiguration is a bitmask where:

- bit 0 toggles dhcp
- bit 1 toggles name resolution
- bit 2 toggles auto IP

For example a value of “2” for the netConfiguration means that the sensor will use a static IP address (both dhcp and auto ip are off) and name resolution via mDNS and NetBIOS is active. When the sensor is configured for a static IP address the user can specify the address using the “staticAddress” field. If this field is not specified the sensor fallbacks to 192.168.0.50. If the netConfiguration field has the value “7” the sensor is configured to use DHCP first and if this fails it will revert to Auto IP which is guaranteed to find a valid IP address.

The fields prefixes with “cur” (e.g. curNetConfiguration) specifies the actual values and are not necessarily identical to the configuration saved by the user. Suppose for example the sensor was configured with DHCP but the sensor is unable to get an IP. In this case after a timeout the sensor reverts to Auto IP which guarantees the sensor will get an IP assigned.

When the configuration is stored (PUT) the fields “curNetConfiguration”, “curHostAddress”, “curSubnet” and “curGateway” MUST be omitted. The following object is returned as response:

```
{"errorCode":<I:code>}
```

An error code 0 means the operation was successfull.

3.11 /changePassword (PUT)

This endpoint allows setting the device password.

3.11.1 Password encoding

The new password is encoded into a JSON object like this:

```
{"oldPassword":<String>, "newPassword":<String>}
```

3.11.2 Return value

```
{"errorCode":<I:code>}
```

An error code 0 means the operation was successfull.

3.12 /comBoardName (GET and PUT)

This endpoint allows reading/writing the device network name.

3.12.1 Name encoding

The new network name is encoded into a JSON object like this:

```
{"name":<String>}
```

3.12.2 Return value

```
{"errorCode":<I:code>}
```

An error code 0 means the operation was successfull.

3.13 /login (PUT)

This endpoint allows logging into the device. Logging in is allows creating a session (token based) so that subsequent operations authenticate via the given token.

3.13.1 Password encoding

```
{"password":<String>}
```

3.13.2 Return value

```
{"errorCode":<I:code>}
```

An error code 0 means the operation was successfull. A special error code with value 100 is returned when the operation was successful but the password is the default one. All the next requests will fail until the password is not changed.

3.14 /logout (PUT)

This endpoint allows logging out from the device. Once a client has logged out its session is no longer valid and a new login is required.

3.14.1 Return value

```
{"errorCode":<I:code>}
```

An error code 0 means the operation was successfull.

3.15 /sensorReset (PUT)

This endpoint allows resetting the sensor configuration to its factory defaults. The configuration that gets changed is the sensor configuration while the network settings, the password and the com board name are not changed.

3.15.1 Return value

```
{"errorCode":<I:code>}
```

An error code 0 means the operation was successfull.

3.16 /comboardReset (PUT)

This endpoint allows resetting the communication board configuration to its factory defaults. The configurations that gets changed are the network settings, the password and the com board name while the sensor configuration is not changed.

This command is also available without authentication for 20 seconds after a startup when the board has an active connection

3.16.1 Return value

```
{"errorCode":<I:code>}
```

An error code 0 means the operation was successfull.

3.17 /updateToken (GET)

This endpoint allows retrieving a new authentication token

3.17.1 Return value

```
{"errorCode":<I:code>, "token":<String>}
```

Where errorCode is 0 on success and token is the new token to be used in subsequent calls.

3.18 /eventLog (GET)

This endpoint returns the list of the latest alarms. For each alarm the sensor tracks detailed information at the beginning of the event and summarized information for the remaining time. An alarm event gets opened as soon as the sensor triggers an alarm condition and it is closed after 3 minutes where the alarm is OFF. If an alarm starts with a given type (e.g. movement detected) and then switches to another type (e.g. masking) then two different events are stored and the first one terminates as soon as the second one starts.

3.18.1 Return value

```
{
  "events": [
    {
      "type": <I:[1-3]>,
      "startTime": <I:value>,
      "endTime": <I:value>,
      "cause": <I:value>
    },
    {
      "type": <I:[1]>,
      "startTime": <I:value>,
      "endTime": <I:value>,
      "alarmDistance": <I:value>,
      "spanDistance": <I:value>,
      "rcs": <I:value>,
      "maxRcs": <I:value>
    }
  ]
}
```

Where:

- type and cause values are the same described in alarm status
- startTime is the time from now when the event start (in milliseconds)
- endTime is the time from now when the event stop (in milliseconds)
- alarmDistance, spanDistance, rcs, maxRcs are present only if the evt-Type is a presenceEvent. Distances are in mm and their meaning is the following:

- alarmDistance is the first distance at which a target was detected when the event started
- spanDistance is the interval from alarmDistance in which a target was detected during this event
- rcs is the rcs that the target had when the event started
- maxRcs is the maximum rcs that target had during this event

3.19 /startProcessUpdate (PUT)

This endpoint is used to notify the sensor about the beginning of an update session. An update session is specific for a device sub component (core sensore, communication board or web server).

3.19.1 Argument encoding

```
{"dst":<I:[0: sensor, 1: comBoard, 2: server]>}
```

3.20 /startManifestUpdate (PUT)

This endpoint is used to notify the sensor about the beginning of a manifest update. The answer contains the chunk size that must be used to transfer data chunks

3.20.1 Return value

```
{ "errorCode":<I>, "maxChunkSize":<I>}
```

Where errorCode is 0 on success and in this case maxChunkSize is populated with the max dimension a chunk shall have.

3.21 /chunkManifestUpdate (PUT)

This endpoint shall be used to transmit a chunk of meta information. The max size of a chunk is returned by startManifestUpdate.

This request needs 2 HTTP special headers + X-Update-Filename: + Content-Range: bytes -/

Binary data (loaded from IFW meta information) shall be placed in the request body.

3.22 /stopManifestUpdate (PUT)

This endpoint informs the sensor that the metainformation has been completely transmitted.

3.22.1 Return value

```
{ "errorCode":<I>}
```

Where errorCode is 0 on success

3.23 /startFileUpdate (PUT)

This endpoint is used to notify the sensor about the beginning of an item update. When the component being updated is either the core sensor or the communication board the item is actually the firmware image for the sub device. If the component being updated is the web server then the item can be any of the file in the web server tree (the web server has several files)

3.23.1 Return value

```
{ "errorCode":<I>, "maxChunkSize":<I>}
```

Where errorCode is 0 on success and in this case maxChunkSize is populated with the max dimension a chunk shall have.

3.24 /chunkFileUpdate

This endpoint shall be used to transmit a chunk of binary data. The max size of a chunk is returned by startFileUpdate.

This request needs 2 HTTP special headers + X-Update-Filename: + Content-Range: bytes -/

In the body of the request must be placed binary data (the chunk must be of the size specified in /startFileUpdate)

3.25 /stopFileUpdate

This endpoint informs the sensor that a file content has been completely transmitted.

3.25.1 Return value

```
{ "errorCode":<I>}
```

Where errorCode is 0 on success

3.26 /stopProcessUpdate

This endpoint informs the sensor that an update process has completed. The client can specify if the update shall be terminated by force (in this case the update is aborted)

3.26.1 Argument

```
{"force":<I>}
```

A non zero value for the “force” parameter means the process shall be aborted

3.26.2 Return value

```
{ "errorCode":<I>}
```

Where errorCode is 0 on success